

Rollei Pro Display Protection


- ▶ 0.3 mm ultra-thinness optical glass
- ▶ Light transmittance > 95%
- ▶ Glas self-adhesive, adhesive power 130 g/m²
- ▶ Scratch-resistant, shatter-/shockproof – only diamonds are harder!
- ▶ With anti-aging, anti-dust, anti-sweat and anti-glare effect
- ▶ Touch and swivel screen friendly
- ▶ Display protection unified with camera



1 Clean the LCD screen with the included wet cleaning paper. Do not use alcohol or any other solvent!



2 Remove the red marked film and align the Rollei Pro Display Protection on the LCD screen. Then firmly press, starting from the middle.




3 The mounting on the small LCD is identical to that of the large display. Finally remove the blue marked film.



Six-layer protection

1. Precision polishing layer
2. 0.3 mm glass layer
3. Frame layer
4. Combination layer
5. Shatter-proof layer
6. Silicone adhesive layer



Technical Specifications

Material	0.3 mm ultra-thinness optical glass
Available for	▶ Canon 1DX, 5DII, 5DIII/5Dr/5Ds, 5DIV, 6D, 7D, 7DII, 60D, 70D, 80D, 100D, 600D, 650D, 700D, 750D, 760D, 1200D/1300D, S110, EOS M, EOS M3, G1X, T5/1200D, T5i/700D ▶ Fuji X-Pro 2, X-100S, X-E2, X-M1, X-T1, X-T2, XT-10, X-70 ▶ Leica D-lux 2, D-lux 6 ▶ Nikon AW1, D4, D5, D90, D500, D600, D610, D700, D750, D800, D800E, D810, D3100, D3200, D3300, D5100, D5300, D5500, D7000, D7100, D7200, DF, J2, J3 ▶ Olympus E-M1/E-M10/EM-10 Mark II/E-M5 II, E-P5, Pen-F ▶ Panasonic LX-7 ▶ Sony A7R/A7S II, A5000/A5100, A6000/A6300, NEX-7, RX 100/II/III ▶ Universal 3.0" 3:2 (65x44 mm), 4:3 (63x 48 mm), 16:9 (68x39 mm)
Content	Rollei Pro Display Protection*, wet cleaning paper, card to detach the screen protector and user instructions

Subject to technical changes.

*The number of screen protectors in the scope of delivery may vary according to the specified model.

